

Step 1: Prep

Pick a spot. Themes-To-Go Peel'N'Sticks adhere well to smooth, indoor surfaces. Recommended and NOT recommended surfaces are listed below.

Measure your spot to ensure you have enough space.

Lay the Peel'N'Stick flat for an hour before installing.

Step 2: Clean

Use a warm damp cloth to wipe down the surface and let it dry completely. DO NOT use any soaps or cleaning agents as they may make your Peel'N'Stick stick poorly.

Step 3: Get Help!

We always recommend having a friend assist you in putting up your Peel'N'Stick. These graphics are big and very sticky.

Step 4: Apply

With help from a friend, start at the top of your Peel'N'Stick and carefully remove it from its backing.

Place one corner on the wall and slowly smooth into place using minimal pressure. If you make a mistake, gently peel the image off the wall and reposition it.

A Yellow plastic squeegee is included with your graphics to eliminate any wrinkles or air bubbles. Start from the middle of the Peel'N'Stick and gently push out to the edges.

Recommended Surfaces

- Smooth Walls
- Painted Dry Wall
- Glass
- Metal
- Sanded Wood (without Lacquer)
- Inside, termperature controlled environments

NOT Recommended Surfaces

- Freshly painted walls. Wait 30 days after painting before you put up your graphic
- Textured Walls
- Unpainted Drywall
- Brick
- Cinder Block
- Porous, textured paneling
- Exterior, non-temperature controlled environments